


THE LOMOND

Collection



WATCH MANUAL

THE STORY

The Lomond Collection; a vintage-inspired timepiece that takes you back in time to the iconic eras of the 1970s. With its timeless and classic design, this watch is a perfect blend of old-world charm and modern functionality.

This manual will guide you through the operation, adjustment and care of your watch, helping you keep it performing and looking its best for years to come.

Jason Monaghan
Owner



HOW TO SET YOUR WATCH



HOW TO SET YOUR WATCH

- 1) Pull out the crown to Pos. B
- 2) Turn the crown clockwise until the previous day's date appears.
- 3) Pull out the crown to Pos. C when the second hand is at the 12 o'clock position.
- 4) Turn the crown until the desired date appears.
- 5) Turn the crown to set hour and minute hands.
(Check that AM / PM is set correctly.)
- 6) Push the crown back in to normal position (Pos. A).
accordance with the time signal.

Note :

* The date will change gradually between 9:00 P.M. and 4:00 A.M. Therefore, do not set the date during this time period or the date may not change properly. If it is necessary to set the calendar during that time period, first change the time to any time outside it, set the date and then reset the correct time.

CARING FOR YOUR WATCH

To keep your watch looking and performing its best, clean it occasionally with a soft, dry cloth and avoid contact with chemicals, perfumes and abrasive surfaces.

Gold and rose gold plating may naturally show signs of wear over time. Avoid polishing compounds or abrasive cleaners, as these can damage the plated finish.

Leather straps should be kept away from water where possible. If wet, allow the strap to dry naturally at room temperature and avoid direct heat.

CARING FOR YOUR WATCH

Mineral glass is durable but can still scratch, so avoid contact with hard or abrasive surfaces.

Always follow the stated water-resistance rating and never operate the crown while the watch is wet or submerged.

Your watch is powered by a VJ42 quartz movement. When the battery is depleted, have it replaced promptly by a competent watchmaker.

When not in use, store your watch somewhere cool, dry and away from direct sunlight.

GET IN TOUCH

SOCIALS

Instagram: @jjmonaghanwatches

Twitter: @jjmonaghan_com

Facebook: @jjmonaghanwatches

GET IN TOUCH

contact@jjmonaghan.com



JJ MONAGHAN